



Turn on Support mode
Help>Record support data



Scan a part using Autoinspect or measure object shape



Export support file
Help>export settings>last 2D scan support

